Removing the Adapter:

New-FD Bayonet Mount

FD/FL Breech-Mount

Press the lens release on your lens and turn to remove adapter Turn the ring on the lens until adapter is removed

Contact Us:

For Information Regarding this and more of our products, please contact us:

www.fotodiox.com

Fot@ioX

FD Lens Adapter

Instruction Manual



*Lens not included

www.fotodiox.com

Mounting the Adapter:

1 Before mounting the adapter on any FD-Mount type, (Regular Lock mount or Breech-Lock Mount) you must place the adapter ring on Install




New-FD Bayonet Mount

2 Set your lens to any aperture except for auto (bayonet mount only)

Bayonet mounts are identified by a red dot next to the lens release button



FD/FL Breech-Mount



Match the lens and adapter markings and turn adapter for bayonet mount. Turn ring on lens for breech mount until securely locked

Operating the Adapter:

If you'd like to operate the lens aperture with the adapter; on your lens, set the aperture to the smallest opening and use the adapter ring



If you'd like to operate the lens aperture with the lens; place the adapter ring on the small aperture icon and control the aperture on the lens



Macro Photography:

Unscrew the glass holder and remove glass for macro photography.

Store Glass in a safe place to avoid scratches

